




-See page 2 for detailed wiring.

- 1. See page 3 for relevant controller system configuration settings.
- 3. Controls and outdoor sensor can be wired or wireless.
- 7. Optional for heat meters.

17. Rotary Isolator must be situated outside of the Protective Zone

- 19. Cooling mode coding resistor - Required for ASHP cooling functionality
- 21. 3rd Party cooling demand is created via closed link on ME & Zone input.



Vaillant Group disclaimer: This drawing is supplied for information and general guidance only. No responsibility is accepted for any errors or omissions contained within or for any cost incurred in rectifying any work relating to it.

Drawn: A.RICE

18/07/2023

REV: A

Appliance(s): 1x aroTHERM Mono, ----

Control(s): 1x sensoCOMFORT

HTG. Circuit(s): 1x RAD - 3rd Party (Heat Only), 1x FCU - 3rd Party (Heat & Cool),

Domestic Hot Water: 1x Cylinder







-See page 2 for detailed wiring.

- 1. See page 3 for relevant controller system configuration settings.
- 3. Controls and outdoor sensor can be wired or wireless.
- 7. Optional for heat meters.

17. Rotary Isolator must be situated outside of the Protective Zone

- 19. Cooling mode coding resistor - Required for ASHP cooling functionality
- 21. 3rd Party cooling demand is created via closed link on ME & Zone input.



31170-1012

Terms and Conditions for Vaillant Schematic Diagrams



PLEASE NOTE THAT THE DIAGRAM PROVIDED IS FOR GENERAL INFORMATION PURPOSES ONLY. THE ADVICE AND INPUT OF A PROFESSIONAL, QUALIFIED, GAS SAFE / MCS INSTALLER MUST BE SOUGHT. VAILLANT IS NOT RESPONSIBLE FOR INSTALLATIONS OR FOR THE PROFESSIONAL DESIGN OF THE SYSTEM.

- All applicable laws and regulations must be followed.
- The Diagram may be subject to alteration at any time.
- Vaillant is not responsible for any inaccuracies or omissions in the information and drawings provided to it and upon which it relies when constructing the diagrams.
- Any reproduction of the design must have the prior permission of Vaillant.
- During the planning, design, installation and later use of the system, all operating instructions must be followed.
- In no circumstances shall Vaillant be liable to you or any other third parties for any loss or damage (including, without limitation, damage for loss of business or loss of profits) arising directly or indirectly from your use of or inability to use, this diagram.
- Vaillant makes no representations or warranties of any kind, express or implied about the completeness, accuracy, reliability or suitability of the diagram for any purpose. Any reliance you place on the diagram is therefore strictly at your own risk.
- These disclaimers and exclusions shall be governed by and construed in accordance with English law.

02	aroTHERM Monoblock
03e	Secondary Circulation Pump
03f	General Pump
05	uniSTOR DHW Cylinder
07f	45/100 L Buffer
08a	Pressure Relief Valve
08c	DHW Inlet Safety Group
08e	Heating / DHW Expansion Vessel
08g	Brine Expansion Vessel
09d	Bypass Valve
09g	Diverter Valve
09h	Fill / Drain Valve
09j	Expansion Vessel Service Valve
09r	Isolation Valve
10c	Non-return Valve
10e	Y Strainer
10i	Flexible Connection
10j	Magnetic Filter
11	Immersion Heater
12	sensoCOMFORT
12b	Heat Pump Interface
12e	Wiring Centre - VR 71
12i	External Controller
12K	High Limit Cut Out
12l	Cylinder Thermostat
12m	Outdoor Temperature Sensor
12p	Wireless Receiver
16	Rotary Isolator
17	Electric Meter
21	Coding Resistor (Cooling)




sensoCOMFORT System Configuration

Not all settings are displayed, commissioning of the controller should be done diligently; going through each adjustable option with consideration to the property and system requirements.

Setting	Value	Setting	Value
Installation		Circuit 2	
Adapt. heat curve:	Deactivated	Circuit type:	Heating
Hybrid manager:	Bivalence pt	OT switch-off threshold:	30°
Heating bivalence point:	-20°	Heat curve:	**Site specific
DHW bivalence point:	-20°	Min. target flow temperature:	15°
Alternative point:	Off	Max. target flow temperature:	45° (Assumed)
ESCO:	Heat + cool off	Set-back mode:	Eco
Back-up boiler:	Off	Room temp. mod.:	Inactive
Conf. ext. input:	Open, deactiv.	Cooling Possible:	Yes
Basic system diagram config.		Min cooling target flow temp:	10° (Assumed)
Basic system diagram code:	8	Zone 1	
FM5 configuration:	3	Zone activated:	Yes
FM5 MO:	Cooling signal	Zone assignment:	No assignmt
HP control module configuration		Zone 2	
MO 2:	Circulation pump	Zone activated:	Yes
MI:	Ext. Cooling Mode	Zone assignment:	No assignmt
Circuit 1		Domestic hot water	
Circuit type:	Heating	Cylinder:	Active
OT switch-off threshold:	30°	Anti-legio. day:	**User preference
Heat curve:	**Site specific	Anti-legio. time:	**User preference
Min. target flow temperature:	15°	Cylinder charging offset:	15 K
Max. target flow temperature:	45° (Assumed)	Cyl. charg. anti-cycl. time:	5 min
Set-back mode:	Eco		
Room temp. mod.:	Inactive		
Cooling Possible:	No		

A	18/07/2023	Added Link to EVU and Warning Triangle 21	2,B
		-	-

REV	DATE	DESCRIPTION	ZONE
-----	------	-------------	------



Vaillant Group disclaimer: This drawing is supplied for information and general guidance only. No responsibility is accepted for any errors or omissions contained within or for any cost incurred in rectifying any work relating to it.

Drawn: A.RICE

18/07/2023

REV: A

Appliance(s): 1x aroTHERM Mono, ----

Control(s): 1x sensoCOMFORT

HTG. Circuit(s): 1x RAD - 3rd Party (Heat Only), 1x FCU - 3rd Party (Heat & Cool),

Domestic Hot Water: 1x Cylinder